



Water Closet & Flushometer Combo

WETS-2450.1410

Product description

Standard, ST-2459 Water Closet and ROYAL 111 SF5M Flushometer.

Compliances & Certifications



(ADA Compliant*, BAA Compliant, BREEAM Water Credit, CalGreen Compliant, EPD, Green Globes Water, HPD, IAPMO, LEED Credit, LEED HPD, LEED Water, Satisfies LEED Credits, cUPC Certified, EPA WaterSense Listed, WELL Building Standard)

Code 24501410

Downloads

- [SS Wall Hung Installation Instructions.pdf](#)
- [Royal Exposed Installation Instructions.pdf](#)
- [EBV-500_550-A Installation Instructions.pdf](#)
- [EBV500-EBV550 Repair and Maintenance Guide.pdf](#)
- [Royal Manual Diaphragm Flushometer Repair and Maintenance Guide.pdf](#)
- [Fixture Brochure.pdf](#)
- [Additional Downloads](#)

Videos

- [Sloan – Company Overview](#)

Details

- Flush Volume: 1.28 gpf (4.8 lpf)

Features

- All organic rubber has been replaced with synthetic compounds
- Critical components, including cover, valve body, control stop and sweat solder kit, are made of semi-red brass
- PERMEX® Synthetic Rubber Diaphragm with Dual Filtered Fixed Bypass
- Valve body, Cover, Tailpiece and Control Stop shall be in compliance with ASTM Alloy Classification for Semi-Red Brass
- Valve shall be in compliance to the applicable sections of ASSE 1037
- Designed to maximize and complement Sloan flushometers
- Universal model works with Sloan flushometers from 1.1 to 1.6 gpf
- Durable, hygienic vitreous china construction with elongated rim
- Syphon jet flushing achieves 1000g Map Scores when used with Sloan flushometers
- IAPMO certified to meet or exceed ASME A112.19.2 standards
- Meets ADA guidelines and ANSI A117.1 requirements when installed accordingly

Components

- Flushometer: Code 3910276
- Water Closet: Code 2102459

Warranty

[View Warranty Information](#)

Notes

All information contained within this document subject to change without notice.

*Compliant with ADA accessibility requirements when installed according to ADA standards.

Static load tested according to the procedure outlined in Section 6.7 of ASME A112.19.2. Not recommended for bariatric use.

